



GRAPHYTE (EU) QUICK START GUIDE




POWER ON TO BRING UP MAIN MENU SELECTIONS

FIRST STEP BEFORE USE



Please go to Setup>Set time, use the keypad arrows to set date/time so you can timestamp your surveys.

SURVEY


NEW SURVEY OPTIONS

- 1) Select Full, LTE, UMTS or GSM
- 2) Select number of cycles and time interval
- 3) Connect charger for extended surveys
- 4) Press  to start survey
- 5) Leave device to complete surveys


POST SURVEY OPTION 1

- 1) Select Show Results
 - 2) Press  for liveSCAN
- Use  **BACK** key to exit

POST SURVEY OPTION 2


- 1) Select Show Summary
- Use  **BACK** key to exit

POST SURVEY OPTION 3



- 1) Select Save Results
- This is only necessary if Auto Save is off
- Use  **BACK** key to exit

SAVED RESULTS



STORED SURVEY

- 1) Select results file you wish to view
 - 2) Select Show Results, Show Summary, or Export Results
- Use  **BACK** key to exit

SETUP


-  Language: ENG/DEU/FRA/ITA/SPA
- Display: Screen brightness and text colours
- Auto off: Auto switch off and dimming
- Documents: Results file types and Auto Save
- Sound: On/Off
- System: Mode and region of operation
- Set Time: Set date and time
- Factory Reset: Return to default settings
- Use  **BACK** key to exit

ABOUT

-  Key reference parameters about the device
- Use  **BACK** key to exit

PC CONNECT

PC CONNECT

- 1) Connect USB cable between device and PC
 - 2) Select ON to enable USB connection, begin results download
 - 3) Copy files required to PC
 - 4) Select OFF to disable connection
- Use  **BACK** key to exit
- You can then view results files on your PC

For more detailed information,
please visit our website at www.siretta.com